

SPARK Fire Ribbon Outdoor Safety Screen Installation

SS and SS-ST models

1.



Position the upper end of the screen into the fireplace opening using the notches on the two upper side tabs.

2.



While keeping the upper end notches intact with the fireplace face, rotate the bottom of the screen inward towards the fireplace. Stop at the position shown on the photograph.

3.



While holding the screen with one hand, use your other hand to slightly bend the center tab up, then continue rotating the screen forward until the center tab can be latched into the slot as shown.

4.



If necessary, slightly bend the left and right bottom tabs inward, to allow the screen to rest inside the fireplace opening.